

Evaluated and Approved Modules for use with QRail per UL 2703 Edition 1	
Manufacturer	Model
Canadian Solar	CS6P-XXX, CS3U-P, Cs3U-MS, Cs3K-P CS3K-MS, CS3K-MS, CS6K-xxxMS, All-BLACK CS6K-xxxMS, CS6U-xxxM, 1500V CS6U-xxxM, CS6U-xxxP, 1500V CS6U-xxxP, CS6X-xxxP, ALL-BLACK CS6K-xxxM, CS6K-xxxM, 1500V CS6K-xxxM, CS6K-xxxP, 1500V CS6K-xxxP, CS6P-xxxP
Conergy	PowerPlus XXX
ET Solar	ET-M660XXXBB, ET-M660XXXWW/WB, ET-P660XXXBB, ET-P660XXXWW/WB
Hanwha Q Cells	Q Pro XXX
Boviet	BVM6610P-xxx, BVM6610M-xxx
Hyundai	HIS-MXXXRG, HIS-SXXXRG
Jinko	60 cell modules model: JKMXXXP-60, 60 JKMxxx-P-60, 60 JKMxxx-P-60B, 60 JKMxxxPP-60, 60 JKMxxxPP-60B, PERC 60 JKMxxxM-60, Plus JKMxxxPP-60(Plus), JKMxxxP-60-J4, JKMxxxP60B-J4, Black JKMxxxPP-60-J4, JKMxxxPP60B-J4, 1500V 60 JKMxxxPP-60-V, 1500V 60 JKMxxxM-60-V, Jinko MX60 JKMSxxxP, MX JKMSxxxPP-60, JKMxxxM-60B, JKMxxxM-60-J4, JKMxxxM60B-J4, JKMSxxxP-60, JKMSxxxP-60-J4, JKMSxxxM-60, JKMSxxxM-60-J4, JKMSxxxPP-60-J4, JKMSxxxPP-60, JKMSxxxM-60B-EP, 72 cell modules model: JKMXXXP-72
LG	LG XXXS2W-A5
Mission Solar	MSExxxSO5K, MSExxxSO5T, MSExxxSO6J, MSEXXXSO4J, MSEXXXMM6J, MSEXXSQ5K, MSEXXSQ5T, MSEXXSQ6S, MSEXXSQ4S
REC	REC TwinPeak 2 Series (BLK), RC TwinPeak 2 BLK2 Series, REC N-Peak
Seraphim Solar	SPR-6MA, SRP-6PA, SRP-6MB, SRP-6MB-BB, SRP-6PB
Silfab	SLA X, SLA-M XXX, SLA-P XXX, SLG-P, SLG-M/SLG X, SSA-M/SSA-P, SSG-M/SSG-P All silver frame
SolarWorld	Sunmodule Plus SWXXX, Sunmodule Plus SWA xxx poly (black/clear), Sunmodule Plus SWA xxx mono (black/clear), Sunmodule SWA xxx XL mono (black/clear), Sunmodule SWA xxx XL poly (black/clear), Sunmodule Bisun SWA xxx XL duo (black/clear)
Sonali Solar	SS 230W to 265W-280W to 320W
Suniva	OPTXXX-60-4-1B0
SunPower	SPR-X21-XXX, SPR-E20-XXX
Trina	60 cell modules model: TSM-PD05.08-XXX, 72 cell modules model: TSM-PD14-XXX, ALL-MAX-PD05.05, ALLMAX M Plus-DD05A.05 (II)-, ALLMAX-PD05A.08, TSM-DD14A(II)-, TSM-DE14A(II)-
Yingli	72 cell modules model: YL-XXX-35B, 60 cell modules model: YL-XXX-29B

Note: XXX refers to the power class in watts (W) of the module. The QRail system is to be used only with modules on this list or with those which include the QRail system in their respective installation manuals.